


Using Fiber with Wireless Press Box (with Dry Pair and Wired Backup)

Use the following steps to set up and connect your press box system to your sideline system via stadium fiber.

1. Make connections as shown below.

Wireless Press Box Unit Rear Panel



STADIUM:
X-Net Fiber from
Sideline System

PC LAN:
Fiber for
X-Ware PC

STADIUM DRY PAIR:
Ports 1–6 for Backup

2. Connect your backup wired BeltPacks for all users.
3. Connect AC power, then do the following:
 - A. Power on the wireless press box unit's UPS.
 - B. Power on the sideline Control Units (CUs). Select Home or Away and allow the CCF to load.
 - C. Power on the press box Radio Packs (RPs).
Note: For this workflow, the press box RPs should be paired to the secondary (bottom) sideline CU.
 - D. Power on wired BeltPacks and make sure TALK buttons are off.
 - E. Access each sideline CU's menu (Wired Settings > Intercom Settings) and verify that all 2-Wire ports are set to AudioCom ("A-C").
4. Connect to X-Ware.
 - A. Power on the press box tablet.
 - B. Launch the screen-sharing software to remotely access the sideline PC.
 - C. Launch the sideline X-Ware (if not already running).
5. Perform the dry pair test and auto-null all of the lines from the sideline using X-Ware's Conference view (under the System Settings menu).
6. Test operation of the press box RPs.
7. After the game, power off and stow away X-System wireless press box components.



Fiber Workflow Reminders:


- Do not turn on the press box CUs.
- RPs should be paired to the secondary (bottom) sideline CU.
- X-Ware access will be a remote connection to the sideline system's X-Ware.

Using Dry Pair with Wireless Press Box (with Wired Backup)

Use the following steps to set up and connect your press box system to your sideline system via dry pair connections.

1. Make connections as shown below.

Wireless Press Box Unit Rear Panel



**STADIUM DRY PAIR:
Ports 1–6**

2. Connect your backup wired BeltPacks for all users.
3. Connect AC power for the wireless press box, then do the following:
 - A. Power on the wireless press box unit's UPS.
 - B. Power on the wireless press box unit's Control Units (CUs). Select Home or Away and allow the CCF to load.
 - C. Power on the press box Radio Packs (RPs).

Note: For this workflow, the press box RPs should be paired to the primary (top) press box CU.
 - D. Power on wired BeltPacks and make sure TALK buttons are off.
4. Connect to X-Ware.
 - A. Power on the press box tablet.
 - B. Launch the press box X-Ware.
5. Perform the dry pair test and auto-null all of the lines from the press box using X-Ware's Conference view (under the System Settings menu).

IMPORTANT: Do not auto-null the sideline CUs and press box CUs at the same time.
6. Test operation of the press box RPs.
7. After the game, power off and stow away X-System wireless press box components.



Dry Pair Workflow Reminders:

- The press box CUs will be turned on.
- RPs should be paired to the primary (top) press box CU.
- X-Ware will control the press box CUs, and it will operate separately from the sideline system's X-Ware.